STATUS SYMBOLS

Description	Example	AutoCAD Command
PRIMARY CONTROL		Hatch = LINE Scale = 1.0 Angle = 135°
LEASE or EASEMENT		Hatch = DASH Scale = 1.0 Angle = 135°
SECONDARY to OTHER FEDERAL AGENCY		Hatch = LINE Scale = 1.0 Angle = 45°
PARTIAL UNDIVIDED INTEREST	do not hatch	(11) designate amount of interest
LIFE ESTATE	do not hatch	designate "SUBJECT TO LIFE ESTATE"
WILDERNESS AREA		Hatch = DOTS Scale = 0.5 Angle = 0°
TRACT CIRCLE	0.08" Romans 0.35" diameter Rapidograph 0 (11)	dashed circle construction
TRACT BOUNDARY and MONUMENTATION	Project boundary 0.026" Class "B" monument 0.07"D Surveyed corner not monumented, 0.05"D Tract boundary, 0.021" Class "A" monument, 0.07"ID-0.10"OD Unsurveyed corner